

CATALOG NUMBER		GTS-THHN	GTS-XHHW	GTS-THXH	GTS-RH
		THHN Cu Conductor KIT	XHHW Cu Conductor KIT	THHN/XHHN Al Conductor KIT	RHW/RHH/USE Cu Conductor KIT
EF-1	Bushing EF-1	6	6	6	
F-1	Bushing F-1			4	
R-1	Bushing R-1				6
E-1	Bushing E-1	4	4		
EF-2	Bushing EF-2	3	3	2	
R-2	Bushing R-2				4
E-2	Bushing E-2	2	2		
F-2	Bushing F-2			1	
R-3	Bushing R-3				2
EF-3	Bushing EF-3	1	1	1/0	
EF-4	Bushing EF-4	1/0	1/0	2/0	
R-4	Bushing R-4				1
E-3	Bushing E-3	2/0	2/0		
F-3	Bushing F-3			3/0	
R-5	Bushing R-5				1/0
E-4	Bushing E-4	3/0	3/0		
R-6	Bushing R-6				2/0
F-4	Bushing F-4			4/0	
R-7	Bushing R-7				3/0
E-5	Bushing E-5	4/0	4/0		

CATALOG NUMBER		GTS-THHN	GTS-XHHW	GTS-THXH	GTS-RH
		THHN Cu Conductor KIT	XHHW Cu Conductor KIT	THHN/XHHN Al Conductor KIT	RHW/RHH/USE Cu Conductor KIT
F-5	Bushing F-5			250	
R-8	Bushing R-8				4/0
EF-5	Bushing EF-5	250	250	300	
B-1	Bushing B-1		300		
AF-1	Bushing AF-1	300		350	
R-9	Bushing R-9				250
BF-1	Bushing BF-1		350	400	
A-1	Bushing A-1	350			
R-10	Bushing R-10				300
E-6	Bushing E-6	400	400		
R-11	Bushing R-11				350
F-6	Bushing F-6			500	
E-7	Bushing E-7	500	500		
R-12	Bushing R-12				500