Changing the battery - Display

Depending on your use and the configuration of your infrastructure, you will have to change the batteries every 2 years or even less often.

We chose to use non-rechargeable batteries for the following reasons :

- For an equilvalent size, rechargeable batteries would only provide approximately half the autonomy of our current solution (currently 2 years and more)
- The extremely low power consumption of our devices would result in a very important Self Discharge phenomenon on rechargeable batteries, which would once more affect autonomy
- The replacement of a battery is a rare and quick task. Maintenance is made easy, compared to having to recharge batteries every couple of
 months

Take a look at our Youtube video, explaining you how to change the battery:

Or see the following instructions:

• Grab the plastic tool provided with your ROOMZ Display, and align it with the groove located in the back of the device (under the 3rd button, when facing the device):





• Pull on the tool, the display's cover will come loose:



• Using a paperclip, unfold the strips sticking on the battery, that will help you slide the battery out:



• Once out, just replace the battery with the new one, by disconnecting and reconnecting the plug:

Hold the wire coming out of the Display (shown by the arrow), as it might slide back in the device once the battery is disconnected



- Finally, gently slide the new battery back in the device
 You can re-use the strips and fold them back in place to make the next change easier. Take care of the wiring before closing the lid